

SUREFOOT SIDESTAND FITTING INSTRUCTIONS

R65/R80/R100 1985 ON (Monolevers)

1. Remove M10 nut, bolt & washer from Left hand riders footpeg
2. Remove M10 bolt & battery overflow pipe holder from frame infill (Just to rear of the swing arm bearing cap) If reusing the battery overflow pipe holder, drill out the M6 captive thread to M8 clearance. (If using sealed battery, overflow pipe bracket not required)
3. Use M8 bolt, washer & nuts supplied to attach rear, upper tab of the Surefoot sidestand bracket (and battery overflow pipe if using) to rear frame infill. Finger tighten only at this point.
4. Pass supplied M10 x 55 bolt through footpeg bracket, frame & lower tab of sidestand (sits on inboard side of frame) Add washer & nut to bolt but DO NOT tighten at this stage of fitting.
5. Select footpeg position on its splines & securely tighten footpeg & sidestand to frame.
6. Tighten all nuts & bolts at this stage
7. Adjust sidestand stop to ensure no interference with rear footpeg and/or luggage

NB: BMW integral panniers may require longer stop bolt

(Not supplied)

****PLEASE NOTE Many components require fitting skills that take years of experience to acquire. Incorrect fitting could cause accidents and/or personal danger. If you do not own the correct tools or the necessary experience then entrust the job to someone who is qualified.**